

Changing the grip from Eko-Aims ELP-pistols

1. Detach the original Eko-Aims grip with ELP-grip weight tool (one weight is holding the grip at its place)



- 2.

Detach the grip holding bolt by pressing the pin, and change it to the longer bolt for wooden grip



3.

Attach the wooden grip to its place, and tighten it with 4mm allen key.

